

Climate gateways

GW630100

Daikin AC errors

Bingenium *
eS
www.besknx.com

Index

1	Machine errors	2
----------	-----------------------	----------


1 Machine errors

Bus	Daikin	Bus	Daikin	Bus	Daikin
1	1	26	AA	51	E3
2	2	27	AH	52	E4
3	3	28	AC	53	E5
4	4	29	AJ	54	E6
5	5	30	AE	55	E7
6	6	31	AF	56	E8
7	7	32	C0	57	E9
8	8	33	C1	58	EA
9	9	34	C2	59	EH
10	0A	35	C3	60	EC
11	0H	36	C4	61	EJ
12	0C	37	C5	62	EE
13	0J	38	C6	63	EF
14	0E	39	C7	64	H0
15	0F	40	C8	65	H1
16	A0	41	C9	66	H2
17	A1	42	CA	67	H3
18	A2	43	CH	68	H4
19	A3	44	CC	69	H5
20	A4	45	CJ	70	H6
21	A5	46	CE	71	H7
22	A6	47	CF	72	H8
23	A7	48	E0	73	H9
24	A8	49	E1	74	HA
25	A9	50	E2	75	HH

Bus	Daikin	Bus	Daikin	Bus	Daikin
76	HC	101	J5	126	LE
77	HJ	102	J6	127	LF
78	HE	103	J7	128	P0
79	HF	104	J8	129	P1
80	F0	105	J9	130	P2
81	F1	106	JA	131	P3
82	F2	107	JH	132	P4
83	F3	108	JC	133	P5
84	F4	109	JJ	134	P6
85	F5	110	JE	135	P7
86	F6	111	JF	136	P8
87	F7	112	L0	137	P9
88	F8	113	L1	138	PA
89	F9	114	L2	139	PH
90	FA	115	L3	140	PC
91	FH	116	L4	141	PJ
92	FC	117	L5	142	PE
93	FJ	118	L6	143	PF
94	FE	119	L7	144	U0
95	FF	120	L8	145	U1
96	J0	121	L9	146	U2
97	J1	122	LA	147	U3
98	J2	123	LH	148	U4
99	J3	124	LC	149	U5
100	J4	125	LJ	150	U6

Bus	Daikin	Bus	Daikin	Bus	Daikin
151	U7	176	30	201	49
152	U8	177	31	202	4A
153	U9	178	32	203	4H
154	UA	179	33	204	4C
155	UH	180	34	205	4J
156	UC	181	35	206	4E
157	UJ	182	36	207	4F
158	UE	183	37	208	50
159	UF	184	38	209	51
160	M0	185	39	210	52
161	M1	186	3A	211	53
162	M2	187	3H	212	54
163	M3	188	3C	213	55
164	M4	189	3J	214	56
165	M5	190	3E	215	57
166	M6	191	3F	216	58
167	M7	192	40	217	59
168	M8	193	41	218	5A
169	M9	194	42	219	5H
170	MA	195	43	220	5C
171	MH	196	44	221	5J
172	MC	197	45	222	5E
173	MJ	198	46	223	5F
174	ME	199	47	224	60
175	MF	200	48	225	61

Bus	Cód
226	62
227	63
228	64
229	65
230	66
231	67
232	68
233	69
234	6A
235	6H
236	6C
237	6J
238	6E
239	6F



KNX products by ingenium



Ingenium, Ingeniería y Domótica S.L.

Parque Tecnológico de Asturias, Parcela 50

33428 Llanera, Asturias, España

T (+34) 985 757 195

tec@besknx.com

www.besknx.com

www.ingeniumsl.com

Liability limitation: The present document is subject to changes or excepted errors. The contents are continuously checked to be according to the hardware and software but deviations cannot be completely excluded. Consequently, any liability for this is not accepted. Please inform us of any suggestion. Every correction will be incorporated in new versions of this manual.

Manual version: v1.0